LOWER OVEN PARTS

For Models: RBD245PDB6, RBD245PDQ6
(BLACK) (DESIGNER WHITE)

24" BUILT−IN ELECTRIC
DOUBLE OVEN
STD−CLEAN LOWER
SELF−CLEAN UPPER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER OVEN PARTS

For Models: RBD245PDB6, RBD245PDQ6
(BLACK) (DESIGNER WHITE)

Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1		Trim, Side
	4450850	RH Black
	4450851	RH White
	4450853	LH Black
	4450854	LH White
		Screw
	4449747	Black Model
	4449041	White
4	4448520	Bumper, Door
7	4452042	Top Chassis
	4449809	Screw
9	4452159	Tube, Vent
	4449154	Screw
10	4451664	Fan & Bracket Assy.
	4449809	Screw
11	4450706	Oven Light Assy
	4449809	Screw
12	4452166	Bulb, Light
13	4452165	Lens, Light
14	4451738	Frame, Front
	4449040	Screw
	4450118	Nut
15	4450491	Gasket, Door
19	4451476	Support, Insulation
25	4454691	Side, Chassis
		(R.H. & L.H.)
	4449809	Screw
26	4451544	Back, Chassis
	4449809	Screw
27		Liner, Oven
		(Not serviceable)
29	4450026	Sensor
	4449154	Screw
37	4451354	Fuse−Thermal
	4449809	Screw
43	4450525	Base, Chassis
	4449154	Screw
49	4448933	Retainer, Gasket
	4449154	Screw
50	4451747	Cover, Back
	4449809	Screw
51		Trim, Bottom
	4448473	Black Model
	4448474	White Model
	4159465	Screw
53	4449845	Support, Bracket
	4449809	Screw

FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

	4449314	Insulation, Wrap
	4450363	Insulation, Back

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN PARTS

For Models: RBD245PDB6, RBD245PDQ6
(BLACK) (DESIGNER WHITE)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN PARTS

For Models: RBD245PDB6, RBD245PDQ6
(BLACK) (DESIGNER WHITE)

Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
4	4448520	Bumper, Door
7	4452042	Top Chassis
	4449809	Screw
9	4452158	Tube, Vent
	4449154	Screw
10	4452165	Lens, Light
11	4450706	Oven Light Assy
12	4452166	Bulb, Light
14	4450415	Frame, Front
	4449040	Screw
	4450118	Nut
15	4449370	Gasket, Door
19	4451476	Support, Insulation
	4449809	Screw
20	4451605	Cap, Spacer
21		Rail, Side
	4450581	Right Side
	4450582	Left Side
	4448444	Grommet
	4449154	Screw
24	4451424	Latch Assy
	4449809	Screw
25	4454691	Side, Chassis (R.H. & L.H.)
	4449809	Screw
26	4451544	Back, Chassis
	4449809	Screw
27		Liner, Oven (Not serviceable)
29	4450026	Sensor
	4449154	Screw
34	4452160	Vent, Center
37	4451442	Thermostat (TOD) (Temp.) SPST
	4449809	Screw
49	4448933	Retainer, Gasket
	4449154	Screw
50	4451747	Cover, Back
	4449809	Screw
53	4449845	Support, Bracket
	4449809	Screw

FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

	4449314	Insulation, Wrap
	4450363	Insulation, Back

LOWER OVEN DOOR PARTS

For Models: RBD245PDB6, RBD245PDQ6
(BLACK) (DESIGNER WHITE)



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1	4451717	Liner, Door
3	4449247	Glass, Inner
5	4451669	Retainer, Glass
	4449809	Screw
6	4451171	Hinge, Door
	4449743	Screw
12		Door Glass, Assy
	4452059	Black Model
	4452060	White Model
13		Door Handle
	4448402	Black Model
	4448403	White Model
14	4450813	Bracket, Handle
	4451040	Screw
21	4451672	Seal, Door Top
23		Retainer, Clip
	4450863	Black Model
	4450864	White Model

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN DOOR PARTS

For Models: RBD245PDB6, RBD245PDQ6
(BLACK) (DESIGNER WHITE)



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1	4451717	Liner, Door
2	4451172	Hinge, Door
	4449743	Screw
3	4449247	Glass, Inner
4	4451720	Insulation, Door
5	4451669	Retainer, Glass
	4449809	Screw
7	4449251	Glass, Inner
12		Door Glass, Assy
	4452059	Black Model
	4452060	White Model
13		Door Handle
	4448402	Black Model
	4448403	White Model
14	4450813	Bracket, Handle
	4451040	Screw
19	4450360	Shield, Heat
	4449809	Screw
20	4451668	Retainer, Glass
	4449809	Screw
21	4451672	Seal, Door Top
23		Retainer, Clip
	4450863	Black Model
	4450864	White Model

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: RBD245PDB6, RBD245PDQ6
(BLACK) (DESIGNER WHITE)



Illus. No.	Part No.	DESCRIPTION
2	4452154	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
6	4448716	Rack, Oven
7	4452153	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: RBD245PDB6, RBD245PDQ6
(BLACK) (DESIGNER WHITE)



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1		Control Panel Assy. W/Membrane Switch
	4451301	Black Model
	4451302	White Model
	4159465	Screw
2	4451032	Gasket, Control Panel
	4449899	Screw
3	4452242	Microcomputer
	4449745	Screw
	4449899	Screw

LITERATURE PARTS

LIT4450409	Installation Instructions
LIT4450568	Use & Care Guide (Oven)
LIT4452022	Tech Sheet (Oven)
LIT3191638	Safer Cooking Tips

TOP VENTING PARTS

For Models: RBD245PDB6, RBD245PDQ6
(BLACK) (DESIGNER WHITE)



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1	4451759	Vent, Exhaust
2	4451744	Blower
3	4451758	Foam, Block
4	4451438	Elbow, Vent−Top
5	4451752	Elbow, Vent−Bottom
11	4449868	Block, Terminal
	3196181	Screw
13	4448547	Vent, (Control Panel)
	4450038	Screw
14		Side, Control Top
	4451597	Right
	4451598	Left
	4449809	Screw
	4449154	Screw
15	4452244	Back, Control
	4449809	Screw
16	4450549	Cover, Top Rear
	4449809	Screw
17	4448664	Clamp
	4449809	Screw
	112432	Nut
18	4450552	Cover, Top Front
	4449809	Screw

OPTIONAL PARTS

For Models: RBD245PDB6, RBD245PDQ6
(BLACK) (DESIGNER WHITE)

Illus. No.	Part No.	DESCRIPTION

PAINT, TOUCH−UP (1/2oz.)

72017	White
261869	Cord Brown
72032	Black

PAINT, SPRAY

350930	White
261900	Citrine White
830864	Black

ADHESIVE

591014	Adhesive Loctite (1/3 oz.)
482338	Sealer, Silastic (3 oz.)

SPLICING WIRES−−25FT. LENGTH

242828	Wire (12 Ga. 150 c Black)
242820	Wire (14 Ga. 150 c Black)
242821	Wire (14 Ga. 150 c Blue)
242822	Wire (14 Ga. 150 c Brown)
242830	Wire (14 Ga. 200 c Brown)
242823	Wire (14 Ga. 150 c Green)
242824	Wire (14 Ga. 150 c Orange)
242829	Wire (12 Ga. 150 c Red)
242825	Wire (14 Ga. 150 c Red)
242831	Wire (14 Ga. 200 c Red)
242826	Wire (14 Ga. 150 c White)
242827	Wire (14 Ga. 150 c Yellow)
242832	Wire (14 Ga. 200 c Yellow)

WIRING HARNESS PARTS

4454920	Harness, Wire STD (Main)
4450953	Conduit, Double
4450800	Screw
4448664	Clamp
4449809	Screw
112432	Nut
4452222	Spacer, Harness
4454835	Tie, Cable
4451761	Support, Wiring
4454842	Tie, Cable

Miscellaneous

4448950	Screw, Install. 8−14 x 1" (4)
814381	Pin Hinge Kit